

RSpeed 1999-2000 NB1 OEM Style Front Lip Spoiler Instructions

Please read through the instructions to make sure you feel comfortable with installation. If you have questions, call our shop for tech support at 678-290-7504.

1. securely lift front of vehicle and remove front wheels.
2. Remove the lower front outer plastic clip of the inner wheel well cover on each side. (See image 1)
3. Remove the 3 screws at the bottom of the inner wheel well liner on each side. (See image 1)
4. Place the lip spoiler up to the vehicle, and use the black round headed bolt to hold it where the plastic clip was. (See image 2) On the inside of the bumper use a washer and nut to hold the corners of the spoiler. Snug, but don't over-tighten.
5. Attach the 2 brackets that swivel to the outermost lower screws of the inner wheel wheel. Snug, but don't over-tighten. (See image 2)
6. With assistance, pull the spoiler up to its location. It should match very well to the bumper.
7. While your assistant holds the spoiler in place, mark where the holes will be drilled from underneath.
8. To drill without interference, remove the screws and bolts from the corners and lower the spoiler.
9. Drill the holes in the bumper and clean up any burrs.
10. Peel up about 2 inches of plastic on the double sided tape on each corner.
11. Place spoiler back up to the bumper and start again the black bolts and lower screws, but don't fully tighten.
12. Place the support plates under the lip spoiler (short ones in center, long ones outside), and run bolts down through the bumper, spoiler, and plates. Place a nuts under the plates. (See images 3 & 4)
13. Once all nuts and bolts are started make sure the lip spoiler aligns well with the bumper.
NOTE: The lip spoiler should fit almost flush and perfectly aligned to the bumper. We have tested fitment in our shop. If there are fitment issues, please re-check the installation process.
14. If everything looks good, peel up the remainder of the double sided tape plastic (See image 5) and begin to tighten the nuts and bolts from the center out, including the black bolts at the end, and the lower screws.
15. Replace the remaining screws that hold the bottom of the wheel wheel liner on each side.
16. Replace the wheels and torque the lug nuts properly.

